Condition 9

1. The block pavours to the car parking and paved areas will be porous Brindle blocks from B&Q or similar
2. Dig to at least 150mm below a damp proof course – with a gradual slope.
3. Set out a sub-base in more than one layer and compact to 100mm.
4. Layer on sand until the space for blocks reaches the desired height when levelled off at falls.
5. Lay the blocks – they should reach 15mm above the level before compacting.
6. Sweep sand into the block joints and compact the surface. Repeat until every joint has been filled.