

SECTION Q: FENCING (NEW)

Q4 NEW FENCING

- 1.1 Remove existing timber fence, concrete posts and any associated vegetation growth. Excavate and remove concrete surrounds cart all waste material to tip.
- 1.2 In areas where fence is removed install *Nylofor-3M* 1.8m high fencing on over-length posts to be set in concrete or panels bolted to wall where possible. New posts to be at 3m centres.
- 1.3 Fencing to be powder coated to RAL 6005 and all spoil is to be removed from site.. CA to inspect new railings on installation.
- 1.4 Backfill excavations around concrete surrounds make up sub-base and make good ground to match existing surfaces, grass seed where necessary.