

The contractor is to check all site dimensions and levels before work starts. **Do not scale** from drawings. Notify the architect of any discrepancies. This drawing must be read with and checked against all structural and other specialist drawings, specification and bills of quantities. Notify the architect of any discrepancies. The contractor is to comply with all current British Standards and Building Regulations whether or not specifically stated on these drawings.

3654-203 A

A X I O M
ARCHITECTS